


Belt Sander

76 mm (3") MODEL 9910 76 mm (3") MODEL 9911



003361



INSTRUCTION MANUAL

⚠ WARNING:

For your personal safety, READ and UNDERSTAND before using. SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

www.makitatools.com

SPECIFICATIONS

Model	9910	9911		
Belt size	76 mm x 457	mm (3" x 18")		
Belt speed	270 m/min. (900 ft./min.)	75 - 270 m/min. (250 - 900 ft./min.)		
Overall length	262 mm (10 - 3/8")			
Net weight	2.6 kg (5.8 lbs)			

- Manufacturer reserves the right to change specifications without notice.
- · Specifications may differ from country to country.

GENERAL SAFETY RULES

USA002-2

(For All Tools)

A WARNING:

Read and understand all instructions. Failure to follow all instructions listed below, may result in electric shock, fire and/or serious personal injury.

SAVE THESE INSTRUCTIONS

Work Area

- Keep your work area clean and well lit. Cluttered benches and dark areas invite accidents.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust. Power tools create sparks which may ignite the dust or fumes.
- Keep bystanders, children, and visitors away while operating a power tool. Distractions can cause you to lose control.

Electrical Safety

4. Double insulated tools are equipped with a polarized plug (one blade is wider than the other.) This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install a polarized outlet. Do not change the plug in any way. Double insulation eliminates the need for the three wire grounded power cord and grounded power supply system.

- Avoid body contact with grounded surfaces such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is grounded.
- Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
- 7. Do not abuse the cord. Never use the cord to carry the tools or pull the plug from an outlet. Keep cord away from heat, oil, sharp edges or moving parts. Replace damaged cords immediately. Damaged cords increase the risk of electric shock
- When operating a power tool outside, use an outdoor extension cord marked "W-A" or "W". These cords are rated for outdoor use and reduce the risk of electric shock.

Personal Safety

- Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use tool while tired or under the influence of drugs, alcohol, or medication. A moment of inattention while operating power tools may result in serious personal injury.
- 10. Dress properly. Do not wear loose clothing or jewelry. Contain long hair. Keep your hair, clothing, and gloves away from moving parts. Loose clothes, jewelry, or long hair can be caught in moving parts.
- 11. Avoid accidental starting. Be sure switch is off before plugging in. Carrying tools with your finger on the switch or plugging in tools that have the switch on invites accidents.
- 12. Remove adjusting keys or wrenches before turning the tool on. A wrench or a key that is left attached to a rotating part of the tool may result in personal injury.
- 13. Do not overreach. Keep proper footing and balance at all times. Proper footing and balance enables better control of the tool in unexpected situations.

14. Use safety equipment. Always wear eye protection. Dust mask, non-skid safety shoes, hard hat, or hearing protection must be used for appropriate conditions. Ordinary eye or sun glasses are NOT eye protection.

Tool Use and Care

- 15. Use clamps or other practical way to secure and support the workpiece to a stable platform. Holding the work by hand or against your body is unstable and may lead to loss of control.
- 16. Do not force tool. Use the correct tool for your application. The correct tool will do the job better and safer at the rate for which it is designed.
- 17. Do not use tool if switch does not turn it on or off. Any tool that cannot be controlled with the switch is dangerous and must be repaired.
- 18. Disconnect the plug from the power source before making any adjustments, changing accessories, or storing the tool. Such preventive safety measures reduce the risk of starting the tool accidentally.
- 19. Store idle tools out of reach of children and other untrained persons. Tools are dangerous in the hands of untrained users.
- 20. Maintain tools with care. Keep cutting tools sharp and clean. Properly maintained tools with sharp cutting edges are less likely to bind and are easier to control.
- 21. Check for misalignment or binding of moving parts, breakage of parts, and any other condition that may affect the tools operation. If damaged, have the tool serviced before using. Many accidents are caused by poorly maintained tools.
- 22. Use only accessories that are recommended by the manufacturer for your model. Accessories that may be suitable for one tool, may become hazardous when used on another tool.

SERVICE

- 23. Tool service must be performed only by qualified repair personnel. Service or maintenance performed by unqualified personnel could result in a risk of injury.
- 24. When servicing a tool, use only identical replacement parts. Follow instructions in the Maintenance section of this manual. Use of unauthorized parts or failure to follow Maintenance instructions may create a risk of electric shock or injury.

USE PROPER EXTENSION CORD: Make sure your extension cord is in good condition. When using an extension cord, be sure to use one heavy enough to carry the current your product will draw. An undersized cord will cause a drop in line voltage resulting in loss of power and overheating. Table 1 shows the correct size to use depending on cord length and nameplate ampere rating. If in doubt, use the next heavier gage. The smaller the gage number, the heavier the cord.

Table 1: Minimum gage for cord

Amnor	Ampere Rating		Total length of cord in feet				
Ampen			25 ft.	50 ft.	100 ft.	150 ft.	
More Than	Not More Than			AWG			
0	6		18	16	16	14	
6	10		18	16	14	12	
10	12		16	16	14	12	
12	16		14	12	Not Reco	mmended	

SPECIFIC SAFETY RULES

USB007-3

DO NOT let comfort or familiarity with product (gained from repeated use) replace strict adherence to sander safety rules. If you use this tool unsafely or incorrectly, you can suffer serious personal injury.

- Hold tool by insulated gripping surfaces when performing an operation where the cutting tool may contact hidden wiring or its own cord. Contact with a "live" wire will make exposed metal parts of the tool "live" and shock the operator.
- Always use safety glasses or goggles. Ordinary eye or sun glasses are NOT safety glasses.
- 3. Hold the tool firmly with both hands.
- Make sure the belt is not contacting the workpiece before the switch is turned on.

- 5. Keep hands away from rotating parts.
- 6. Do not leave the tool running. Operate the tool only when hand-held.
- This tool has not been waterproofed, so do not use water on the workpiece surface.
- 8. Ventilate your work area adequately when you perform sanding operations.
- Use of this tool to sand some products, paints and wood could expose user to dust containing hazardous substances. Use appropriate respiratory protection.

SAVE THESE INSTRUCTIONS

⚠ WARNING:


MISUSE or failure to follow the safety rules stated in this instruction manual may cause serious personal injury.

SYMBOLS USD204-1

The followings show the symbols used for tool.

V volts	alternating current
A amperes	Class II Construction
Hz hertz	m/minmeter per minute

FUNCTIONAL DESCRIPTION



Lock button
 Switch trigger

⚠ CAUTION:

 Always be sure that the tool is switched off and unplugged before adjusting or checking function on the tool.

Switch action

↑ CAUTION:

- Before plugging in the tool, always check to see that the switch trigger actuates properly and returns to the "OFF" position when released.
- Switch can be locked in "ON" position for ease of operator comfort during extended use. Apply caution when locking tool in "ON" position and maintain firm grasp on tool.

To start the tool, simply pull the switch trigger. Release the switch trigger to stop.

For continuous operation, pull the switch trigger and then push in the lock button.


To stop the tool from the locked position, pull the switch trigger fully, then release it.

Speed adjusting dial

For 9911 only

The belt speed can be infinitely adjusted between 75 m (250 ft.) and 270 m (900 ft.) per minute by turning the speed adjusting dial to a given number setting from 1 to 6. Higher speed is obtained when the dial is turned in the direction of number 6; lower speed is obtained when it is turned in the direction of number 1.

Select the proper speed for the workpiece to be sanded.



1. Speed adjusting dial


⚠ CAUTION:

- If the tool is operated continuously at low speeds for a long time, the motor will get overloaded, resulting in tool malfunction.
- The speed adjusting dial can be turned only as far as 6 and back to 1. Do not force it past 6 or 1, or the speed adjusting function may no longer work.

ASSEMBLY


↑ CAUTION:

Always be sure that the tool is switched off and unplugged before carrying out any work on the tool.




Installing or removing abrasive belt

Pull the lever all the way out and install the belt over the rollers, then return the lever to the original position.




When installing the belt, make sure that the direction of the arrow on the back of the belt corresponds to the one on the tool itself.




Adjusting belt tracking

Switch on the tool and make sure that the belt is aligned properly. If the edge of the belt extends beyond the edge of the steel plate or the edge of the belt retracts more than 8 mm (5/16") away from the edge of the steel plate, use the adjusting screw to adjust the belt tracking.



- 1. Steel plate
- 2. Adjusting screw



- 1. Dust spout
- 2. Dust bag

Dust bag

Attach the dust bag onto the dust spout. The dust spout is tapered. When attaching the dust bag, push it onto the dust spout firmly as far as it will go to prevent it from coming off during operation.

When the dust bag is about half full, remove the dust bag from the tool and pull the fastener out. Empty the dust bag of its contents, tapping it lightly so as to remove particles adhering to the insides which might hamper further collection.

NOTE:

 If you connect a Makita vacuum cleaner to this tool, more efficient and cleaner operations can be performed.

OPERATION

Sanding operation

⚠ CAUTION:

 The tool should not be in contact with the workpiece surface when you turn the tool on or off. Otherwise a poor sanding finish or damage of the belt may result.


Hold the tool firmly with both hands. Turn the tool on and wait until it attains full speed. Then gently place the tool on the workpiece surface. Keep the belt flush with the workpiece at all times and move the tool back and forth.

Never force the tool. The weight of the tool applies adequate pressure. Excessive pressure may cause stalling, overheating of the motor, burning of the workpiece and possible kickback.

MAINTENANCE

⚠ CAUTION:


 Always be sure that the tool is switched off and unplugged before attempting to perform inspection or maintenance.



Replacing carbon brushes

Remove and check the carbon brushes regularly. Replace when they wear down to the limit mark. Keep the carbon brushes clean and free to slip in the holders. Both carbon brushes should be replaced at the same time. Use only identical carbon brushes.

1. Limit mark



1. Screwdriver

2. Brush holder cap

Use a screwdriver to remove the brush holder caps. Take out the worn carbon brushes, insert the new ones and secure the brush holder caps.

To maintain product SAFETY and RELIABILITY, repairs, any other maintenance or adjustment should be performed by Makita Authorized or Factory Service Centers, always using Makita replacement parts.

ACCESSORIES

↑ CAUTION:

 These accessories or attachments are recommended for use with your Makita tool specified in this manual. The use of any other accessories or attachments might present a risk of injury to persons. Only use accessory or attachment for its stated purpose.

If you need any assistance for more details regarding these accessories, ask your local Makita service center.

- Abrasive belts
- Clamp

Memo			

Memo			

First-Class
Postage
Required

Post Office will
not deliver
without proper
postage.

Makita U.S.A., Inc. 14930 Northam Street

La Mirada, CA 90638-5753

Hdallaallaalldalalddaladdalallalall

MAIL THIS PORTION

Your answers to the following questions are appreciated.

I.This product was p	urchased	from:			3. How did you	learn abou	ıt this prodı	ıct:	
Home Center		Other ()	Magazine		R	adio	
Hardware/Lumber	Store				From Deale	er	E:	khibition	
Tool Distributor					Newspape	r	Fr	om Friend	t
Industrial Supply					Store Displ	ay	P	revious Us	sage
Construction Supp	oly				Catalog		_ o	ther (
. Use of the product	is intend	ed for:			4. Most favore	d points are	e:		
Construction Trade	e				Design		R	epair Serv	/ice
Industrial Mainten	ance				Features		D	urability	
Home Maintenand	e				Size		Po	ower	
Hobby					Price		_ o	ther (
Other ()				Makita Bra	nd			
DATE PURCHASED	. — . —				MODEL NO.				
DATE PURCHASED MONTH	DAY		YE,		MODEL NO.				
MONTH			YE,					NTUS	SEX
MONTH		PANY NAME	YE/	AR				NTUS Single	SEX M
MONTH			YEA	AR					
MONTH INTL. LAST NAM			YE	AR					
MONTH			YE	AR					
MONTH INTL. LAST NAM STREET ADRESS			YE	AR			Marriec	Single	
MONTH INTL. LAST NAM STREET ADRESS				AR		NE		Single	
MONTH INTL. LAST NAM STREET ADRESS CITY		PANY NAME		AR	SERIAL NO.	NE NE	Married	Single	
MONTH INTL. LAST NAM STREET ADRESS CITY		PANY NAME		AR	SERIAL NO.	NE NE	Married	Single	

Paste

Paste

Paste

Facsimile No: (714) 522-8133

Paste

Past

Paste

Paste

D--4-

FACTORY SERVICE CENTERS

1-800-4-MAKITA

RETAIN THIS PORTION FOR YOUR RECORDS

ALABAMA

2365 Pelham Parkway Pelham, AL 35124 (205) 620-1791

ADIZONA

3707 E. Broadway Rd., Ste. 6 Phoenix, AZ 85040 (602) 437-2850

ARKANSAS

Shackleford Shopping Center 240 South Shackleford Rd., Little Rock, AR 72211 (501) 224-5733

CALIFORNIA 41850 Christy St. Fremont, CA 94538-5107

(510) 657-9881 1421 N. Clovis Ave., Ste. 112

Fresno, CA 93727 (559) 252-5166

14930 Northam St. La Mirada, CA 90638-5753 (714) 522-8088

1970 Fulton Avenue Sacramento, CA 95825

1440 South "E" Street San Bernardino, CA 92408

7674 Clairemont Mesa Blvd. San Diego, CA 92111 (858) 278-4471

Campbell CA 95008-0501 (408) 379-0377

16735 Saticoy St., Ste. 105 Van Nuys, CA 91406 (818) 782-2440

COLOBADO 11839 E. 51st Ave

Denver, CO 80239-2709 (303) 371-2850

EI OBIDA 620 Douglas Ave. Suite 1302

Altamonte Springs, FL 32714 (407) 774-6000

750 East Sample Road Pompano Beach, FL 33064 (954) 781-6333

Thompson Center Waters 5501 W. Waters Ave., Ste. 406 Tampa, FL 33634 (813) 886-8292

GEORGIA

4680 River Green Parkway Duluth, GA 30096-2566 (770) 476-8911

ILLINOIS

1450 Feehanville Dr. Mt. Prospect, IL 60056-6011 (847) 297-3100

8403 Michigan Road, Unit 1 Indianapolis, IN 46268 (317) 334-9980

8819 W 95th St Overland Park, KS 66212 (913) 642-1111

1215 S. Hurstbourne Parkway Louisville, KY 40222 (502) 326-3740

LOUISIANA

5626 Jefferson Hwy Harahan, LA 70123 (504) 733-4138

MARYLAND

7541 - 45 Ritchie Highway Glen Burnie, MD 21061 (410) 590-0160

MASSACHUSETTS

232 Providence Hwy Westwood, MA 02090 (617) 461-9754

MINNESOTA 6427 Penn Ave. South Richfield, MN 55423

(612) 869-5199 MISSOURI

9876 Watson Road

St. Louis. MO 63126-2221 (314) 909-9889

NEBRASKA 4129 S. 84th St. Omaha NF 68127

NEVADA 3375 S. Decatur Blvd.

Suites, 22 - 24

(609) 655-1212

(702) 368-4277 NEW JERSEY 251 Herrod Blvd. Dayton, NJ 08810-1539

Las Vegas, NV 89102

Springwater Plaza 364 Wilmington W. Chester

6200 Babcock Blvd

NEW YORK

4917 Genessee Street Cheektowaga, NY 14225 (716) 685-9503

131-35 31st Ave Flushing, NY 11354 (718) 886-0971

NORTH CAROLINA 3501-G S. Tryon St. Charlotte, NC 28217

(704) 527-0611

6253 F Main St Columbus, OH 43213 (614) 860-0222

6370 Doorl Dood Parma Heights, OH 44130 (440) 843-7555

1617 F Kemper Rd Sharonville, OH 45246 (513) 771-0788

OKLAHOMA 552 E. Memorial Road Oklahoma City OK 73114

Portland OR 97209

OREGON

PENNSYLVANIA

Glen Mills PA 19342 (610) 459-4122

Pittsburgh, PA 15237 (412) 366-6363

PUERTO RICO

200 Guavama St Hato Rey, PR 00917 (787) 250-8776

TENNESSEE 4655 Nolensville Rd

Nashville, TN 37211 (615) 331-9922

12801 Stemmons Fwy Ste 809 Farmers Branch, TX 75234 (972) 243-1150

12701 Directors Dr Stafford, TX 77477-3701 (281) 565-8665

3453 IH-35 North, Ste. 101 San Antonio, TX 78219 (210) 228-0676

145 E. 1300 S., Ste. 101 Salt Lake City, UT 84115 (801) 359-3410

WASHINGTON 22220 84th Ave. So., Bldg. A Kent. WA 98032 (253) 395-8055

WISCONSIN Lincoln Plaza Shopping Ctr. 2245 S. 108th St. West Allis, WI (414) 541-4776

CUSTOMER'S RECORD

When you need service: Send	Date Purchased
complete tool (prepaid) to one of the Makita Factory Service	Dealer's Name & Address
Centers listed, or to an Authorized Makita Service Center. Be sure	
to attach a letter to the outside of the carton detailing the problem	Model No.
with your tool.	Serial No.

WARNING

Some dust created by power sanding, sawing, grinding, drilling, and other construction activities contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm. Some examples of these chemicals are:

- lead from lead-based paints,
- crystalline silica from bricks and cement and other masonry products, and
- arsenic and chromium from chemically-treated lumber.

Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: work in a well ventilated area, and work with approved safety equipment, such as those dust masks that are specially designed to filter out microscopic particles.

MAKITA LIMITED ONE YEAR WARRANTY

Warranty Policy

Every Makita tool is thoroughly inspected and tested before leaving the factory. It is warranted to be free of defects from workmanship and materials for the period of ONE YEAR from the date of original purchase. Should any trouble develop during this one year period, return the COMPLETE tool, freight prepaid, to one of Makita's Factory or Authorized Service Centers. If inspection shows the trouble is caused by defective workmanship or material, Makita will repair (or at our option, replace) without charge.

This Warranty does not apply where:

- repairs have been made or attempted by others:
- repairs are required because of normal wear and tear:
- the tool has been abused, misused or improperly maintained:
- alterations have been made to the tool.

IN NO EVENT SHALL MAKITA BE LIABLE FOR ANY INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES FROM THE SALE OR USE OF THE PRODUCT. THIS DISCLAIMER APPLIES BOTH DURING AND AFTER THE TERM OF THIS WARRANTY.

MAKITA DISCLAIMS LIABILITY FOR ANY IMPLIED WARRANTIES, INCLUDING IMPLIED WARRANTIES OF "MERCHANTABILITY" AND "FITNESS FOR A SPECIFIC PURPOSE," AFTER THE ONE YEAR TERM OF THIS WARRANTY.

This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Some states do not allow limitation on how long an implied warranty lasts, so the above limitation may not apply to you.

MAKITA MANUFACTURING EUROPE LTD

ROAD 7, HORTONWOOD INDUSTRIAL ESTATE TELFORD, SHROPSHIRE TF1 4GP, ENGLAND